# **Chapter 3: Newtonian Fluids**

CM4650 Polymer Rheology Michigan Tech



Navier-Stokes Equation

$$\rho \left( \frac{\partial \underline{v}}{\partial t} + \underline{v} \cdot \nabla \underline{v} \right) = -\nabla p + \mu \nabla^2 \underline{v} + \rho \underline{g}$$

1

© Faith A. Morrison, Michigan Tech U.

# **Chapter 3: Newtonian Fluid Mechanics**


#### **TWO GOALS**

•Derive governing equations (mass and momentum balances


•Solve governing equations for velocity and stress fields


### **QUICK START**

<u>First</u>, before we get deep into derivation, let's do a Navier-Stokes problem to get you started in the mechanics of this type of problem solving.



2





# Engineering Quantities of Interest

In more complex flows, we can use general expressions that work in all cases.

(any flow)

volumetric flow rate

$$Q = \iint\limits_{S} \left. (\hat{n} \cdot \underline{v}) \right|_{surface} dS$$

average velocity

$$\langle v_z \rangle = \frac{\iint_S |(\hat{n} \cdot \underline{v})|_{surface} dS}{\iint_S dS}$$

Using the general formulas will help prevent errors.

Here,  $\hat{n}$  is the outwardly pointing unit normal of dS; it points in the direction "through" S

© Faith A. Morrison, Michigan Tech U.

The stress tensor was invented to make the calculation of fluid stress easier.


Total stress tensor,  $\underline{\Pi}$ :

$$\underline{\underline{\Pi}} \equiv p\underline{\underline{I}} + \underline{\underline{\tau}}$$

(any flow, small surface)

Force on the surface 
$$dS = \hat{n} \cdot (-\underline{\underline{\Pi}}) dS$$

(using the stress convention of *Understanding Rheology*)



Here,  $\hat{n}$  is the outwardly pointing unit normal of dS; it points in the direction "through" S

To get the total force on the macroscopic surface  $S_{ij}$ we integrate over the entire surface of interest.

Fluid force on the surface S 
$$\underline{F} = \iint_{S} \left[ \hat{n} \cdot \left( -p\underline{I} - \underline{\tau} \right) \right]_{surface} dS$$

$$\begin{pmatrix} F_x \\ F_y \\ F_z \end{pmatrix}_{xyz} = \iint_S (\hat{n}_x \quad \hat{n}_y \quad \hat{n}_z) \cdot \begin{pmatrix} -p - \tau_{xx} & \tau_{xy} & \tau_{xz} \\ \tau_{yx} & -p - \tau_{yy} & \tau_{yz} \\ \tau_{zx} & \tau_{zy} & -p - \tau_{zz} \end{pmatrix}_{xyz} dS$$

 $\hat{n}$ ,  $\underline{\tau}$  and p evaluated at the surface dS

(using the stress convention of *Understanding Rheology*)

© Faith A. Morrison, Michigan Tech U.

## **Engineering Quantities of Interest**

(any flow)

force on the surface, S


Using the general formulas will help prevent errors (like forgetting the pressure).


$$\underline{F} = \iint_{S} \left[ \hat{n} \cdot \left( -p\underline{I} - \underline{\tau} \right) \right]_{surface} dS$$


z-component of force on the surface, S


$$F_{z} = \hat{e}_{z} \cdot \iint_{S} \left[ \hat{n} \cdot \left( -p\underline{I} - \underline{\tau} \right) \right]_{surface} dS$$


(using the stress convention of Understanding Rheology)

























# 









































#### Molecular Forces (continued)

The same logic applies in the 2-direction and the 3-direction

$$\begin{aligned} f_1 &= \hat{n} \cdot \left( \Pi_{11} \hat{e}_1 + \Pi_{21} \hat{e}_2 + \Pi_{31} \hat{e}_3 \right) dS \\ f_2 &= \hat{n} \cdot \left( \Pi_{12} \hat{e}_1 + \Pi_{22} \hat{e}_2 + \Pi_{32} \hat{e}_3 \right) dS \\ f_3 &= \hat{n} \cdot \left( \Pi_{13} \hat{e}_1 + \Pi_{23} \hat{e}_2 + \Pi_{33} \hat{e}_3 \right) dS \end{aligned}$$

Assembling the force vector:

$$\begin{split} \underline{f} &= f_1 \hat{e}_1 + f_2 \hat{e}_2 + f_3 \hat{e}_3 \\ &= dS \ \hat{n} \cdot \left( \Pi_{11} \hat{e}_1 + \Pi_{21} \hat{e}_2 + \Pi_{31} \hat{e}_3 \right) \hat{e}_1 \\ &+ dS \ \hat{n} \cdot \left( \Pi_{12} \hat{e}_1 + \Pi_{22} \hat{e}_2 + \Pi_{32} \hat{e}_3 \right) \hat{e}_2 \\ &+ dS \ \hat{n} \cdot \left( \Pi_{13} \hat{e}_1 + \Pi_{23} \hat{e}_2 + \Pi_{33} \hat{e}_3 \right) \hat{e}_3 \end{split}$$

33

© Faith A. Morrison, Michigan Tech U.

#### Molecular Forces (continued)

Assembling the force vector:

$$\underline{f} = f_1 \hat{e}_1 + f_2 \hat{e}_2 + f_3 \hat{e}_3$$

$$= dS \, \hat{n} \cdot \left( \Pi_{11} \hat{e}_1 + \Pi_{21} \hat{e}_2 + \Pi_{31} \hat{e}_3 \right) \hat{e}_1$$

$$+ dS \, \hat{n} \cdot \left( \Pi_{12} \hat{e}_1 + \Pi_{22} \hat{e}_2 + \Pi_{32} \hat{e}_3 \right) \hat{e}_2$$

$$+ dS \, \hat{n} \cdot \left( \Pi_{13} \hat{e}_1 + \Pi_{23} \hat{e}_2 + \Pi_{33} \hat{e}_3 \right) \hat{e}_3$$


$$= dS \, \hat{n} \cdot \left[ \Pi_{11} \hat{e}_1 \hat{e}_1 + \Pi_{21} \hat{e}_2 \hat{e}_1 + \Pi_{31} \hat{e}_3 \hat{e}_1 \right.$$

$$+ \Pi_{12} \hat{e}_1 \hat{e}_2 + \Pi_{22} \hat{e}_2 \hat{e}_2 + \Pi_{32} \hat{e}_3 \hat{e}_2$$

$$+ \Pi_{13} \hat{e}_1 \hat{e}_3 + \Pi_{23} \hat{e}_2 \hat{e}_3 + \Pi_{33} \hat{e}_3 \hat{e}_3 \right]$$

linear combination of dyadic products = **tensor** 

34



#### Momentum Balance (continued)

Polymer Rheology

Final Assembly:

$$\begin{pmatrix} \textit{rate of increase} \\ \textit{of momentum in } V \end{pmatrix} = \begin{pmatrix} \textit{net flux of} \\ \textit{momentum into } V \end{pmatrix} + \begin{pmatrix} \textit{sum of} \\ \textit{forces on } V \end{pmatrix}$$

$$\iiint\limits_{V} \frac{\partial}{\partial t} (\rho \underline{v}) dV = - \iiint\limits_{V} \nabla \cdot (\rho \underline{v}\underline{v}) dV + \iiint\limits_{V} \rho \underline{g} \ dV - \iiint\limits_{V} \nabla \cdot \underline{\underline{\Pi}} \ dV$$

$$\iiint\limits_{V} \left[ \frac{\partial \rho \underline{v}}{\partial t} + \nabla \cdot \left( \rho \underline{v} \underline{v} \right) - \rho \underline{g} \right. \\ \left. + \nabla \cdot \underline{\prod} \right] dV = 0$$

Because V is arbitrary, we may conclude:

$$\frac{\partial \rho \underline{v}}{\partial t} + \nabla \cdot \left( \rho \underline{v} \underline{v} \right) - \rho \underline{g} + \nabla \cdot \underline{\underline{\Pi}} = 0$$
 Microscopic momentum balance

39

© Faith A. Morrison, Michigan Tech U.

#### Momentum Balance (continued)

Polymer Rheology

Microscopic momentum balance

$$\frac{\partial \rho \underline{v}}{\partial t} + \nabla \cdot (\rho \underline{v}\underline{v}) - \rho \underline{g} + \nabla \cdot \underline{\underline{\Pi}} = 0$$

After some rearrangement:

$$\rho \left( \frac{\partial \underline{v}}{\partial t} + \underline{v} \cdot \nabla \underline{v} \right) = -\nabla \cdot \underline{\underline{\Pi}} + \rho \underline{g}$$

$$\rho \frac{D\underline{v}}{Dt} = -\nabla \cdot \underline{\underline{\Pi}} + \rho \underline{g}$$
Equation of Motion

Now, what to do with  $\Pi$  ?

0

**Momentum Balance** 

(continued)

Polymer Rheology

Now, what to do with  $\prod$  ?

Pressure is part of it.

#### **Pressure**

*definition*: An isotropic force/area of molecular origin. Pressure is the same on any surface drawn through a point and acts normally to the chosen surface.

$$pressure = p \ \underline{\underline{I}} = p \ \hat{e}_1 \hat{e}_1 + p \ \hat{e}_2 \hat{e}_2 + p \ \hat{e}_3 \hat{e}_3 = \begin{pmatrix} p & 0 & 0 \\ 0 & p & 0 \\ 0 & 0 & p \end{pmatrix}_{123}$$

Test: what is the force on a surface with unit normal  $\hat{n}$ ?

41

© Faith A. Morrison, Michigan Tech U.

Momentum Balance (continued)

Polymer Rheology

back to our question,

Now, what to do with  $\Pi$  ?

Pressure is part of it.

There are other, nonisotropic stresses

#### Extra Molecular Stresses

definition: The extra stresses are the molecular stresses that are not isotropic

$$\underline{\underline{\tau}} \equiv \underline{\underline{\Pi}} - p \, \underline{\underline{I}} \qquad \qquad \text{(other sign convention:} \\ \underline{\underline{\tilde{\tau}}} = \underline{\underline{\tilde{\Pi}}} + p\underline{\underline{I}} \text{)}$$


Extra stress


tensor, i.e. everything complicated in molecular deformation

Now, what to do with  $\, au\,$  ?

This becomes the central question of rheological study

42





**Momentum Balance** 

(continued)

Polymer Rheology

Microscopic momentum balance

$$\rho \left( \frac{\partial \underline{v}}{\partial t} + \underline{v} \cdot \nabla \underline{v} \right) = -\nabla \cdot \underline{\underline{\Pi}} + \rho \underline{g}$$

Equation of Motion

In terms of the extra stress tensor:

$$\rho \left( \frac{\partial \underline{v}}{\partial t} + \underline{v} \cdot \nabla \underline{v} \right) = -\nabla p - \nabla \cdot \underline{\underline{\tau}} + \rho \underline{g}$$

Equation of Motion

Cauchy Momentum Equation

Components in three coordinate systems (our sign convention): http://www.chem.mtu.edu/~fmorriso/cm310/Navier2007.pdf

45

© Faith A. Morrison, Michigan Tech U.

**Momentum Balance** 

(continued)

Polymer Rheology

**Newtonian Constitutive equation** 

$$\underline{\underline{\tau}} = -\mu \Big( \nabla \underline{\underline{v}} + (\nabla \underline{\underline{v}})^T \Big)$$

•for incompressible fluids (see text for compressible fluids)

•is empirical

•may be justified for some systems with molecular modeling calculations

Note:  $\underline{\tilde{t}} = +\mu(\nabla \underline{v} + (\nabla \underline{v})^T)$ 

(IFM choice: (opposite)

46

#### **Momentum Balance**

(continued)

Polymer Rheology

How is the Newtonian Constitutive equation related to Newton's Law of Viscosity?

$$\underline{\underline{\tau}} = -\mu \Big( \nabla \underline{v} + (\nabla \underline{v})^T \Big)$$

 $\tau_{21} = -\mu \frac{\partial v_1}{\partial x_2}$ 

•incompressible fluids

- •incompressible fluids
- •rectilinear flow (straight lines)
- •no variation in  $x_3$ -direction

47

© Faith A. Morrison, Michigan Tech U.

#### Momentum Balance (continued)

Polymer Rheology

Back to the momentum balance . . .

$$\rho \left( \frac{\partial \underline{v}}{\partial t} + \underline{v} \cdot \nabla \underline{v} \right) = -\nabla p - \nabla \cdot \underline{\underline{\tau}} + \rho \underline{g} \quad \text{Equation of Motion}$$

$$\underline{\underline{\tau}} = -\mu \left( \nabla \underline{v} + (\nabla \underline{v})^T \right)$$

We can incorporate the Newtonian constitutive equation into the momentum balance to obtain a momentum-balance equation that is specific to incompressible, Newtonian fluids

48

Momentum Balance (continued)

Navier-Stokes Equation  $\rho\left(\frac{\partial \underline{v}}{\partial t} + \underline{v} \cdot \nabla \underline{v}\right) = -\nabla p + \mu \nabla^2 \underline{v} + \rho \underline{g}$ •incompressible fluids
•Newtonian fluids

Note: The Navier-Stokes is unaffected by the stress sign convention because neither  $\underline{\tau}$  nor  $\underline{\tau}$  appear.

