

CM3110
Transport I
Part II: Heat Transfer



***Applied Heat Transfer:
Heat Exchanger Modeling,
Sizing, and Design***



Professor Faith Morrison


Department of Chemical Engineering
Michigan Technological University

© Faith A. Morrison, Michigan Tech U. ¹

Applied Heat Transfer

Before turning to radiation (last topic) we will discuss a few practical applications

How can we use Fundamental Heat Transfer to understand real devices like heat exchangers?



© Faith A. Morrison, Michigan Tech U. ²

Applied Heat Transfer

**The Simplest Heat Exchanger:
Double-Pipe Heat exchanger - counter current**

The heat transfer from the outside to the inside is just heat flux in an annular shell

© Faith A. Morrison, Michigan Tech U.

Applied Heat Transfer

Example 4: Heat flux in a cylindrical shell

Assumptions:

- long pipe
- steady state
- k = thermal conductivity of wall
- h_1, h_2 = heat transfer coefficients at R_1 and R_2

Maybe we can use heat transfer coefficient to understand forced-convection heat exchangers. . .
BUT . . .

© Faith A. Morrison, Michigan Tech U.

Applied Heat Transfer

BUT: The temperature difference between the fluid and the wall varies along the length of the heat exchanger.

The Simplest Heat Exchanger:
Double-Pipe Heat exchanger - counter current

How can we develop a model so that we can use the concept of h to characterize heat exchangers?

© Faith A. Morrison, Michigan Tech U.

Applied Heat Transfer

Let's look at the solution for radial conduction in an annulus

Example 4: Heat flux in a solid cylindrical shell

Solution:

$$\frac{q_r}{A} = \frac{c_1}{r}$$

Flux is not constant

$$T = -\frac{c_1}{k} \ln r + c_2$$

Boundary conditions?

© Faith A. Morrison, Michigan Tech U.

Applied Heat Transfer

Example 4: Heat flux in a cylindrical shell, Newton's law of cooling boundary Conditions

Results: Radial Heat Flux in a Solid Cylindrical Shell

$$T - T_{b2} = \frac{(T_{b1} - T_{b2}) \left(\ln \left(\frac{R_2}{r} \right) + \frac{k}{h_2 R_2} \right)}{\frac{k}{h_2 R_2} + \ln \left(\frac{R_2}{R_1} \right) + \frac{k}{h_1 R_1}}$$

$$\frac{q_r}{A} = \frac{(T_{b1} - T_{b2})}{\frac{1}{h_2 R_2} + \frac{1}{k} \ln \left(\frac{R_2}{R_1} \right) + \frac{1}{h_1 R_1}} \left(\frac{1}{r} \right)$$


© Faith A. Morrison, Michigan Tech U.

Applied Heat Transfer

Example 4: Heat flux in a solid cylindrical shell

Solution for Heat Flux:

$$\frac{q_r}{A} = \frac{(T_{b1} - T_{b2})}{\frac{1}{h_2 R_2} + \frac{1}{k} \ln \left(\frac{R_2}{R_1} \right) + \frac{1}{h_1 R_1}} \left(\frac{1}{r} \right)$$



Calculate Total Heat flow through any chosen r:

(including $r = R_1$ and $r = R_2$)


$$Q = \frac{q_r}{A} (2\pi r L) = \frac{(T_{b1} - T_{b2})(2\pi L)}{\frac{1}{h_2 R_2} + \frac{1}{k} \ln \left(\frac{R_2}{R_1} \right) + \frac{1}{h_1 R_1}}$$

Note that total heat flow is proportional to bulk ΔT and (almost) area of heat transfer

© Faith A. Morrison, Michigan Tech U.

Applied Heat Transfer

Total Heat flow through any chosen r :
(including $r = R_1$ and $r = R_2$)



$$Q = \frac{q_r}{A} (2\pi rL) = \frac{(T_{b1} - T_{b2})(2\pi L) R_1 \left(\frac{1}{R_1}\right)}{\frac{1}{h_2 R_2} + \frac{1}{k} \ln\left(\frac{R_2}{R_1}\right) + \frac{1}{h_1 R_1}}$$

Note that total heat flow is proportional to bulk ΔT and (almost) area of heat transfer

© Faith A. Morrison, Michigan Tech U.

Applied Heat Transfer—Define **Overall** Heat-Transfer Coefficient, U

Overall Heat Transfer Coefficient, U


$$Q = UA\Delta T = UA(T_{b1} - T_{b2})$$

this equation serves as the definition of U

A = area of heat transfer (not always unambiguous)
 ΔT = driving temperature difference

Example: in a pipe

Do we use inner or outer area?



© Faith A. Morrison, Michigan Tech U.

Applied Heat Transfer

Overall heat transfer coefficients in pipe

Area must be specified when U is reported

$$Q = U_1 A_1 \Delta T$$

$$= \left(\frac{1}{\frac{1}{h_2 R_2} + \frac{1}{k} \ln \frac{R_2}{R_1} + \frac{1}{h_1 R_1}} \right) (2 \pi R_1 L) (T_{b1} - T_{b2})$$

$$Q = U_2 A_2 \Delta T$$

$$= \left(\frac{1}{\frac{1}{h_2 R_2} + \frac{1}{k} \ln \frac{R_2}{R_1} + \frac{1}{h_1 R_1}} \right) (2 \pi R_2 L) (T_{b1} - T_{b2})$$

11
© Faith A. Morrison, Michigan Tech U.

Applied Heat Transfer

Heat flux in a cylindrical shell: $Q = UA(T_{b1} - T_{b2})$

But, in an actual heat exchanger, T_{b1} and T_{b2} vary along the length of the heat exchanger

What kind of average ΔT do we use?

12
© Faith A. Morrison, Michigan Tech U.

Applied Heat Transfer

The Simplest Heat Exchanger:
Double-Pipe Heat exchanger - counter current

T_1 cold, T_2 less cold, T'_1 less hot, T'_2 hot, T , inner bulk temperature, T' , outer bulk temperature, Δx , L

We will do an open-system energy balance on a differential section to determine the correct average temperature difference to use.

13
 © Faith A. Morrison, Michigan Tech U.

Applied Heat Transfer

The Simplest Heat Exchanger:
Double-Pipe Heat exchanger - counter current


Another way of looking at it:

m_{inside} , T_1 , Inside System, m_{inside} , T_2 , Q , Outside System, $m_{outside}$, T'_1 , T'_2 , $m_{outside}$

$Q_{in}^{inside} = Q = -Q_{in}^{outside}$

14
 © Faith A. Morrison, Michigan Tech U.


The Simplest Heat Exchanger:
Double-Pipe Heat exchanger - counter current



Another way of looking at it:

Can do three balances:


1. Balance on the inside system



$$Q_{in}^{inside} = Q = -Q_{in}^{outside}$$

15
© Faith A. Morrison, Michigan Tech U.


The Simplest Heat Exchanger:
Double-Pipe Heat exchanger - counter current



Another way of looking at it:

Can do three balances:

1. Balance on the inside system
2. Balance on the outside system



$$Q_{in}^{inside} = Q = -Q_{in}^{outside}$$

16
© Faith A. Morrison, Michigan Tech U.

The Simplest Heat Exchanger:
Double-Pipe Heat exchanger - counter current

Another way of looking at it:

Can do three balances:

1. Balance on the inside system
2. Balance on the outside system
3. Overall balance

$$Q_{in}^{inside} = q = -Q_{in}^{outside}$$

17
© Faith A. Morrison, Michigan Tech U.

The Simplest Heat Exchanger:
Double-Pipe Heat exchanger - counter current

Another way of looking at it:

We can do:



- a macroscopic balances over the **entire** heat exchanger, or
- a *pseudo* microscopic balance over a slice of the heat exchanger

$$Q_{in}^{inside} = q = -Q_{in}^{outside}$$

18
© Faith A. Morrison, Michigan Tech U.

The Simplest Heat Exchanger:
Double-Pipe Heat exchanger - counter current

Another way of looking at it:

We can do:

- a macroscopic balance over the entire heat exchanger, or
- a *pseudo* microscopic balance over a slice of the heat exchanger

All the details of the algebra are here:
www.chem.mtu.edu/~fmorriso/cm310/double_pipe.pdf

19
 © Faith A. Morrison, Michigan Tech U.

Applied Heat Transfer


Pseudo Microscopic Energy Balance on a slice of the heat exchanger

Open system energy balance on a differential volume:

$$\cancel{\Delta E_p} + \cancel{\Delta E_k} + \Delta H = Q_{in} + \cancel{W_{s,on}}$$

$$\Delta H = Q_{in}$$

INSIDE BALANCE



recall: Δ is out-in

20
 © Faith A. Morrison, Michigan Tech U.

Applied Heat Transfer

Pseudo Microscopic Energy Balance on a slice of the heat exchanger

$$\Delta H = Q_{in}$$

INSIDE BALANCE

recall: Δ is out-in

© Faith A. Morrison, Michigan Tech U. ²¹

Applied Heat Transfer

Pseudo Microscopic Energy Balance on a slice of the heat exchanger

Adiabatic Heat Exchanger $\rightarrow Q_{in} = 0$

OVERALL BALANCE

$$\Delta E_p + \Delta E_k + \Delta H = Q_{in} + W_{s,on}$$

$$\Delta H = 0$$

© Faith A. Morrison, Michigan Tech U. ²²

Applied Heat Transfer

energy balance on overall differential system $\Delta H = 0$

$$= \Delta H_{inner\ system} + \Delta H_{outer\ system}$$

$$= \Delta Q_{in,inner} + \Delta Q_{in,outer} = 0$$

heat into inner differential system heat into outer differential system

divide by Δx and take the limit as Δx goes to zero:


$$\left(\frac{dQ_{in,inner}}{dx} \right) = - \left(\frac{dQ_{in,outer}}{dx} \right)$$

$$\equiv \frac{dQ_{in}}{dx}$$

This expression characterizes the rate of change of heat transferred with respect to distance down the heat exchanger

© Faith A. Morrison, Michigan Tech U. ²³

The Simplest Heat Exchanger:
Double-Pipe Heat exchanger - counter current



Result of inside balance:

$$\frac{dQ_{inner}}{dx} = m\hat{c}_p \left(\frac{dT}{dx} \right)$$

Result of outside balance:

$$-\frac{dQ_{outer}}{dx} = m'\hat{c}'_p \left(\frac{dT'}{dx} \right)$$

Result of overall balance:

$$-\frac{dQ_{outer}}{dx} = \frac{dQ_{inner}}{dx} \equiv \frac{dQ_{in}}{dx}$$

Solve for temperature derivatives, and subtract:

$$\frac{dQ_{in}}{dx} \left(\frac{1}{m'\hat{c}'_p} - \frac{1}{m\hat{c}_p} \right) = \left(\frac{dT'}{dx} - \frac{dT}{dx} \right)$$


$$= \frac{d(T' - T)}{dx}$$

This depends on $T' - T$

All the details of the algebra are here:
www.chem.mtu.edu/~fmorriso/cm310/double_pipe.pdf

© Faith A. Morrison, Michigan Tech U. ²⁴

Analysis of double-pipe heat exchanger



Rate of change of heat transferred with respect to distance down the heat exchanger

Driving force for heat transfer

Question: How can we write $\frac{dQ_{in}}{dx}$ in terms of $T' - T$?

Answer: Define an "overall" heat transfer coefficient, U


25
© Faith A. Morrison, Michigan Tech U.

Analysis of double-pipe heat exchanger

$$\frac{d(T' - T)}{dx} = \frac{dQ_{in}}{dx} \left(\frac{1}{m' \hat{C}_p} - \frac{1}{m \hat{C}_p} \right)$$

Want to integrate to solve for $T' - T$,

but this is a function of $T' - T$




For the **differential slice of the heat exchanger** that we are considering (modeling our ideas on Newton's law of cooling),

$$\frac{dQ_{in}}{dA} = (?) (T' - T)$$

26
© Faith A. Morrison, Michigan Tech U.

Analysis of double-pipe heat exchanger

For the **differential slice of the heat exchanger** that we are considering (modeling our ideas on Newton's law of cooling),



$$\frac{dQ_{in}}{dA} = (?) (T' - T)$$

$$\begin{aligned} dQ_{in} &= (U)dA(T' - T) \\ &= U(2\pi R dx)(T' - T) \end{aligned}$$

$$\frac{dQ_{in}}{dx} = U(2\pi R)(T' - T)$$

This is the missing piece that we needed.

We can write $\frac{dQ_{in}}{dx}$ in terms of $T' - T$ if we define an "overall" heat transfer coefficient, U

© Faith A. Morrison, Michigan Tech U. ²⁷

Analysis of double-pipe heat exchanger

$$\frac{d(T' - T)}{dx} = \frac{dQ_{in}}{dx} \left(\frac{1}{m' \hat{C}_p'} - \frac{1}{m \hat{C}_p} \right)$$

$$\frac{dQ_{in}}{dx} = 2\pi R U (T' - T)$$

$$\frac{d(T' - T)}{dx} = 2\pi R U (T' - T) \left(\frac{1}{\hat{C}_p' m'} - \frac{1}{\hat{C}_p m} \right)$$

$$\frac{d(T' - T)}{(T' - T)} = \left[2\pi R U \left(\frac{1}{\hat{C}_p' m'} - \frac{1}{\hat{C}_p m} \right) \right] dx$$

© Faith A. Morrison, Michigan Tech U. ²⁸

Analysis of double-pipe heat exchanger

$$\frac{d(T' - T)}{(T' - T)} = \left[2\pi RU \left(\frac{1}{\hat{C}'_p m'} - \frac{1}{\hat{C}_p m} \right) \right] dx$$

$$\Phi \equiv T' - T$$

$$\alpha_0 \equiv 2\pi RU \left(\frac{1}{\hat{C}'_p m'} - \frac{1}{\hat{C}_p m} \right) \quad (\text{we'll assume } U \text{ is constant})$$

$$\frac{d\Phi}{\Phi} = \alpha_0 dx$$

$$\int \frac{d\Phi}{\Phi} = \alpha_0 \int dx$$


$$\ln \Phi = \alpha_0 x + \text{constant}$$

$$\Phi = \Phi_0 e^{\alpha_0 x}$$

B.C:
 $x = 0, T - T' = T_1 - T'_1$

© Faith A. Morrison, Michigan Tech U. ²⁹


Analysis of double-pipe heat exchanger



Temperature profile in a double-pipe heat exchanger:

$$\frac{T' - T}{T'_1 - T_1} = e^{\alpha_0 x} \quad \alpha_0 = 2\pi RU \left(\frac{1}{\hat{C}'_p m'} - \frac{1}{\hat{C}_p m} \right)$$

© Faith A. Morrison, Michigan Tech U. ³⁰



Analysis of double-pipe heat exchanger

Temperature profile in a double-pipe heat exchanger:

$$\frac{T' - T}{T'_1 - T_1} = e^{-\alpha_0 x}$$

$$\alpha_0 = 2\pi RU \left(\frac{1}{\hat{C}'_p m'} - \frac{1}{\hat{C}_p m} \right)$$

Useful result, but what we **REALLY** want is an easy way to relate $Q_{in, overall}$ to inlet and outlet temperatures.

At the exit: $x = L$, $(T - T') = (T_2 - T'_2)$

$$\ln \left(\frac{T'_2 - T_2}{T'_1 - T_1} \right) = U (2\pi RL) \left(\frac{1}{\hat{C}'_p m'} - \frac{1}{\hat{C}_p m} \right)$$

32
© Faith A. Morrison, Michigan Tech U.

Analysis of double-pipe heat exchanger

$$\ln\left(\frac{T'_2 - T_2}{T'_1 - T_1}\right) = U(2\pi RL) \left(\frac{1}{\hat{C}'_p m'} - \frac{1}{\hat{C}_p m} \right)$$

The $m\hat{C}_p$ terms appear in the overall macroscopic energy balances. We can therefore rearrange this equation by replacing the $m\hat{C}_p$ terms with Q_{in} :

$$Q_{in} = UA \frac{(T'_2 - T_2) - (T'_1 - T_1)}{\ln\left(\frac{T'_2 - T_2}{T'_1 - T_1}\right)}$$

total heat transferred in exchanger

average temperature driving force

$$Q_{in} = m\hat{C}_p(T_2 - T_1)$$

$$\Rightarrow \frac{1}{m\hat{C}_p} = \frac{T_2 - T_1}{Q_{in}}$$

$$-Q_{in} = m\hat{C}'_p(T'_1 - T'_2)$$

$$\Rightarrow \frac{1}{m\hat{C}'_p} = \frac{-(T'_1 - T'_2)}{Q_{in}}$$

33
© Faith A. Morrison, Michigan Tech U.


Analysis of double-pipe heat exchanger

FINAL RESULT:

$$Q = U \underbrace{(2\pi RL)}_A \frac{(T'_1 - T_1) - (T'_2 - T_2)}{\ln\left(\frac{T'_1 - T_1}{T'_2 - T_2}\right)}$$

$$Q = UA\Delta T_{lm}$$

ΔT_{lm} is the correct average temperature to use for the overall heat-transfer coefficients in a double-pipe heat exchanger.



$\equiv \Delta T_{lm}$
=log-mean temperature difference

34
© Faith A. Morrison, Michigan Tech U.

Analysis of double-pipe heat exchanger

FINAL RESULT:

$$Q = UA \left[\frac{(\Delta T_{left} - \Delta T_{right})}{\ln \left(\frac{\Delta T_{left}}{\Delta T_{right}} \right)} \right]$$

$$\equiv \Delta T_{lm}$$

ΔT_{lm} = log-mean temperature difference

$$Q = UA \Delta T_{lm}$$

ΔT_{lm} is the correct average temperature to use for the overall heat-transfer coefficients in a double-pipe heat exchanger.



35
© Faith A. Morrison, Michigan Tech U.

Analysis of double-pipe heat exchanger

Example: Heat Transfer in a Double-Pipe Heat Exchanger: *Geankoplis 4th ed. 4.5-4*

Water flowing at a rate of 13.85 kg/s is to be heated from 54.5 to 87.8°C in a double-pipe heat exchanger by 54,430 kg/h of hot gas flowing counterflow and entering at 427°C ($\hat{C}_{pm} = 1.005 \text{ kJ/kg K}$). The overall heat-transfer coefficient based on the outer surface is $U_o = 69.1 \text{ W/m}^2 \text{ K}$. Calculate the exit-gas temperature and the heat transfer area needed.

36
© Faith A. Morrison, Michigan Tech U.



Optimizing heat exchangers

Optimizing Heat Exchangers

double-pipe:

$$Q = UA\Delta T_{lm}$$

To increase Q appreciably, we must increase A , i.e. R_f

But:

- only small increases possible
- increasing R_f decreases h

39
© Faith A. Morrison, Michigan Tech U.

Optimizing heat exchangers

1-1 Shell and Tube Heat Exchanger

(Same as double pipe H.E.)

1 shell
1 tube

1-2 Shell and Tube Heat Exchanger


1 shell
2 tube

Geankoplis 4th ed.,
p292

40
© Faith A. Morrison, Michigan Tech U.

Optimizing heat exchangers


Cross Baffles in Shell-and-Tube Heat Exchangers



© Faith A. Morrison, Michigan Tech U.⁴¹

Optimizing heat exchangers

And other more complex arrangements:



2 shell
4 tube

© Faith A. Morrison, Michigan Tech U.⁴²

Optimizing heat exchangers

For double-pipe heat exchanger:

$$Q = UA\Delta T_{lm}$$

For shell-and-tube heat exchangers:

$$Q = UA[\Delta T_{lm}(F_T)]$$

$\underbrace{\hspace{10em}}_{\equiv \Delta T_m}$

calculated correction factor (obtain from experimentally determined charts)

correct mean temperature difference for shell-and-tube heat exchangers

43
© Faith A. Morrison, Michigan Tech U.

Optimizing heat exchangers

F_T
Shell-and-Tube Heat Exchangers
(1-1 exchanger, $F_T = 1$)

T_{hi} = hot, in
 T_{ho} = hot, out
 T_{ci} = cold, in
 T_{co} = cold, out

Efficiency is low when F_T is below $F_{T,min}$

Geankoplis 4th ed., p295

1-2 Shell and Tube H.E.

$Z = \frac{T_{hi} - T_{ho}}{T_{co} - T_{ci}}$

$Y = \frac{T_{co} - T_{ci}}{T_{hi} - T_{ci}}$

2-4 Shell and Tube H.E.

$Z = \frac{T_{hi} - T_l}{T_{co} - T}$

$Y = \frac{T_{co} - T_{ci}}{T_{hi} - T_{ci}}$


44
© Faith A. Morrison, Michigan Tech U.

Heat Exchanger Design

Heat Exchanger Design

To calculate Q , we need both inlet and outlet temperatures:

$$Q = UA\Delta T_m = UA(F_T\Delta T_{lm})$$



$$Q = UA \left[\frac{(\Delta T_{left} - \Delta T_{right})}{\ln \left(\frac{\Delta T_{left}}{\Delta T_{right}} \right)} \right]$$

What if the outlet temperatures are unknown?
i.e. the design/spec problem.

© Faith A. Morrison, Michigan Tech U. ⁴⁵


Heat Exchanger Design

Example Problem:
How will this heat exchanger perform?

Water flowing at a rate of 0.723 kg/s enters the inside of a countercurrent, double-pipe heat exchanger at 300 K and is heated by an oil stream that enters at 385 K at a rate of 3.2 kg/s . The heat capacity of the oil is 1.89 kJ/kgK , and the average heat capacity of the water of the temperature range of interest is 4.192 kJ/kgK . The overall heat-transfer coefficient of the exchanger is $300 \text{ W/m}^2\text{K}$, and the area for heat transfer is 15.4 m^2 . What is the total amount of heat transferred?

© Faith A. Morrison, Michigan Tech U. ⁴⁶

Heat Exchanger Design


Example Problem:
 How will this heat exchanger perform?

Water flowing at a rate of 0.723 kg/s enters the inside of a countercurrent, double-pipe heat exchanger at 300 K and is heated by an oil stream that enters at 385 K at a rate of 3.2 kg/s . The heat capacity of the oil is 1.89 kJ/kgK , and the average heat capacity of the water of the temperature range of interest is 4.192 kJ/kgK . The overall heat-transfer coefficient of the exchanger is $300 \text{ W/m}^2\text{K}$, and the area for heat transfer is 15.4 m^2 . What is the total amount of heat transferred?

You try.

© Faith A. Morrison, Michigan Tech U. ⁴⁷

Heat Exchanger Design

Example Problem:
 How will this heat exchanger perform?

To calculate unknown outlet temperatures:

Procedure:

1. Guess Q
2. Calculate outlet temperatures
3. Calculate ΔT_{lm}
4. Calculate Q
5. Compare, adjust, repeat

© Faith A. Morrison, Michigan Tech U. ⁴⁸

Heat Exchanger Effectiveness

Heat Exchanger Effectiveness

Consider a *counter-current* double-pipe heat exchanger:

© Faith A. Morrison, Michigan Tech U. ⁵¹

Heat Exchanger Effectiveness

Energy balance cold side:

$$Q_{in,cold} = Q = (mC_p)_{cold}(T_{co} - T_{ci})$$

Energy balance hot side:

$$Q_{in,hot} = -Q = (mC_p)_{hot}(T_{ho} - T_{hi})$$

Equate:

$$(m\hat{C}_p)_{cold}(T_{co} - T_{ci}) = -(m\hat{C}_p)_{hot}(T_{ho} - T_{hi})$$

$$\frac{(mC_p)_{hot}}{(mC_p)_{cold}} = \frac{(T_{co} - T_{ci})}{-(T_{ho} - T_{hi})} = \frac{\Delta T_c}{\Delta T_h}$$

© Faith A. Morrison, Michigan Tech U. ⁵²

Heat Exchanger Effectiveness

$$\frac{(m\hat{C}_p)_{hot}}{(m\hat{C}_p)_{cold}} = \frac{\Delta T_{cold}}{\Delta T_{hot}}$$

Case 1: $\begin{cases} (mC_p)_{hot} > (mC_p)_{cold} \\ \Delta T_c > \Delta T_h \end{cases}$ cold fluid = minimum fluid

We want to compare the amount of heat transferred in this case to the amount of heat transferred in a **PERFECT** heat exchanger.

distance along the exchanger

53
© Faith A. Morrison, Michigan Tech U.

Heat Exchanger Effectiveness

If the heat exchanger were **perfect**, $T_{hi} = T_{co}$ (no heat left un-transferred)

cold side:
 $Q_{A=\infty} = (m\hat{C}_p)_{cold} (T_{co} - T_{ci})$

distance along the exchanger

this temperature difference only depends on inlet temperatures

$$Q_{A=\infty} = (m\hat{C}_p)_{cold} (T_{hi} - T_{ci})$$

54
© Faith A. Morrison, Michigan Tech U.

Heat Exchanger Effectiveness

Heat Exchanger Effectiveness, ε

$$\varepsilon \equiv \frac{Q}{Q_{A=\infty}}$$

$$\Rightarrow Q = \varepsilon (mC_p)_{cold} (T_{hi} - T_{ci})$$

cold fluid = minimum fluid

if ε is known, we can calculate Q without iterations

55
© Faith A. Morrison, Michigan Tech U.

Heat Exchanger Effectiveness

$$\frac{(m\hat{c}_p)_{hot}}{(m\hat{c}_p)_{cold}} = \frac{\Delta T_{cold}}{\Delta T_{hot}}$$

Case 2: $\left\{ \begin{array}{l} (mC_p)_{hot} < (mC_p)_{cold} \\ \Delta T_c < \Delta T_h \end{array} \right.$ hot fluid = minimum fluid

distance along the exchanger

56
© Faith A. Morrison, Michigan Tech U.

Heat Exchanger Effectiveness

If the heat exchanger were *perfect*, $T_{ho} = T_{ci}$ (no heat left un-transferred)

hot side:
 $Q_{A=\infty} = -(m\hat{C}_p)_{hot} (T_{ho} - T_{hi})$

$A = \infty$

The same temperature difference as before (inlets)

distance along the exchanger

$Q_{A=\infty} = (m\hat{C}_p)_{hot} (T_{hi} - T_{ci})$

© Faith A. Morrison, Michigan Tech U. ⁵⁷

Heat Exchanger Effectiveness

Heat Exchanger Effectiveness $\varepsilon \equiv \frac{Q}{Q_{A=\infty}}$

$\Rightarrow Q = \varepsilon (mC_p)_{hot} (T_{hi} - T_{ci})$

hot fluid = minimum fluid

in general,

$Q = \varepsilon (mC_p)_{\min} (T_{hi} - T_{ci})$

if ε is known, we can calculate Q without iterations

© Faith A. Morrison, Michigan Tech U. ⁵⁸

Heat Exchanger Effectiveness

But where do we get ϵ ?

The same equations we use in the trial-and-error solution can be combined algebraically to give ϵ as a function of $(mC_p)_{min}$, $(mC_p)_{max}$.



counter-current flow:

$$\epsilon = \frac{1 - e^{\frac{-UA}{(mC_p)_{min}} \left(1 - \frac{(mC_p)_{min}}{(mC_p)_{max}} \right)}}{1 - \frac{(mC_p)_{min}}{(mC_p)_{max}} e^{\frac{-UA}{(mC_p)_{min}} \left(1 - \frac{(mC_p)_{min}}{(mC_p)_{max}} \right)}}$$

This relation is plotted in Geankoplis, as is the relation for co-current flow.

© Faith A. Morrison, Michigan Tech U. ⁵⁹

Heat Exchanger Effectiveness for Double-pipe or 1-1 Shell-and-Tube Heat Exchangers




note: Geankoplis' $C_{min} = (mC_p)_{min}$

Geankoplis 4th ed., p299

© Faith A. Morrison, Michigan Tech U. ⁶⁰

Heat Exchanger Effectiveness



Example Problem:
How will this heat exchanger perform?

Water flowing at a rate of 0.723 kg/s enters the inside of a countercurrent, double-pipe heat exchanger at 300 K and is heated by an oil stream that enters at 385 K at a rate of 3.2 kg/s . The heat capacity of the oil is 1.89 kJ/kgK , and the average heat capacity of the water of the temperature range of interest is 4.192 kJ/kgK . The overall heat-transfer coefficient of the exchanger is $300 \text{ W/m}^2\text{K}$, and the area for heat transfer is 15.4 m^2 . What is the total amount of heat transferred?

You try.

© Faith A. Morrison, Michigan Tech U. ⁶¹


Heat Exchanger Effectiveness

Heat Exchanger Fouling


- material deposits on hot surfaces
- rust, impurities
- strong effect when boiling occurs

scale adds an additional resistance to heat transfer

clean



fouled



© Faith A. Morrison, Michigan Tech U. ⁶²

Heat Exchanger Effectiveness

Heat transfer resistances

$$U_{i\ or\ o} = \frac{1}{\frac{1}{h_i R_i} + \frac{1}{k} \ln\left(\frac{R_o}{R_i}\right) + \frac{1}{h_o R_o}}$$

resistance due to interface

resistance due to limited thermal conductivity


add effect of fouling

$$U_{i\ or\ o} = \frac{1}{\frac{1}{h_i R_i} + \frac{1}{h_{di} R_i} + \frac{1}{k} \ln\left(\frac{R_o}{R_i}\right) + \frac{1}{h_{do} R_o} + \frac{1}{h_o R_o}}$$

see Perry's Handbook, or Geankoplis 4th ed. Table 4.9-1, page 300 for values of h_d

63
© Faith A. Morrison, Michigan Tech U.

Heat Exchanger Fouling



Geankoplis, 4th edition, p300

TABLE 4.9-1. Typical Fouling Coefficients (P3, N1)

	h_f ($W/m^2 \cdot K$)
Distilled and seawater	11 350
City water	5680
Muddy water	1990-2840
Gases	2840
Vaporizing liquids	2840
Vegetable and gas oils	1990



TABLE 4.9-2. Typical Values of Overall Heat-Transfer Coefficients in Shell-and-Tube Exchangers (H1, P3, W1)

	U ($W/m^2 \cdot K$)
Water to water	1140-1700
Water to brine	570-1140
Water to organic liquids	570-1140
Water to condensing steam	1420-2270
Water to gasoline	340-570
Water to gas oil	140-340
Water to vegetable oil	110-285
Gas oil to gas oil	110-285
Steam to boiling water	1420-2270
Water to air (finned tube)	110-230
Light organics to light organics	230-425
Heavy organics to heavy organics	55-230

64
© Faith A. Morrison, Michigan Tech U.

Next:

- Heat transfer with phase change
- Evaporators
- Radiation
- *DONE*



© Faith A. Morrison, Michigan Tech U. ⁶⁵